

Installation Guides

Master Flash® Fix-A-Flash

1. Measure the pipe to determine where, if necessary, to trim an opening 20-30% smaller than pipe diameter.
2. Slide the Master Flash® down the pipe, using a non-petroleum-based lubricant to ease installation.
3. Press Master Flash® down, bending it to conform to roof profile or irregularities. A blunt tool will help to form flashing to tight roof angles.
4. Apply sealant between the base of the flashing and the roof.
5. Use fasteners to complete sealing. For a secure installation, fastener spacing must not exceed 1.5" (38mm).

