

## Master Flash® Multi-Flash

1. Select an appropriate Master Flash® Multi-Flash with a pipe range that goes below and beyond fitting. If necessary, follow the lines clearly shown on the flashing and create an opening 20-30% smaller than pipe diameter.
2. If using this product as a Retrofit, cut down the side in the clearly-marked flange.
3. Slide the Master Flash® Multi-Flash down the pipe, using a non-petroleum-based lubricant to ease installation. For Retrofit applications, wrap the product around the pipe.
4. Press Master Flash® Multi-Flash down, bending it to conform to roof profile or irregularities. A blunt tool will help to form flashing to tight roof angles.
5. Apply sealant between the base of the flashing and the roof, as well as at the top of the flange.
6. Place the stainless-steel gripper on the flange to close and secure the Master Flash® Multi-Flash.
7. Tighten the stainless-steel gripper.
8. Use fasteners to complete sealing. For a secure installation, fastener spacing must not exceed 1.5" (38mm).
9. Additional sealant may be applied between the flashing and the pipe. Apply as needed.

